


Sample Reverse Manifold and Piping Diagram for the AdvantagePlus.
 Check Local Codes for specific piping requirements.



THE INFORMATION CONTAINED IN THIS MANUAL IS FOR GUIDANCE ONLY. THE FACTORY CANNOT BE HELD RESPONSIBLE FOR ANY PROBLEMS ENCOUNTERED WITH INSTALLATION METHODS SHOWN.

IF THERE IS A BACK FLOW PREVENTER, OR ANY TYPE OF A NO RETURN VALVE IN THE SYSTEM, THEN YOU MUST INSTALL AN ADDITIONAL TEE FOR A SUITABLE POTABLE THERMAL EXPANSION TANK.

